



New to the timeclock or don't remember from last season?

TURN IT ON: Switch on right hand side at bottom of clock

GETTING STARTED

- **QUESTIONS TO ANSWER:**

1. Do you want to start where you left off? **NO** (usually)
2. Enter model code: **0083261**
3. Do you want shot clock? **NO** (for hockey) **YES** (for ringette)
4. Timeout? **NO** (usually)

SET THE TIME:

1. **SET**
2. **TIME**
3. **20:00** (or 5:00 for the warmup)
4. **YES**
5. **PERIOD: 1 (or 2 or 3)**

START THE CLOCK:

- Use the hand control with button at end. You will also use this to stop the time when the whistle blows.

SET THE SCORE:

1. **HOME** or **GUEST**
2. **SCORE**
3. **1 (+1 for each additional goal)**

PENALTIES:

- **SET A PENALTY:**

1. **HOME PENALTY** or **GUEST PENALTY**
2. **2:00** (usually unless a non-standard penalty)
3. **YES**
4. **PLAYER NUMBER: 01** (for first player penalty, **02** for additional penalty on same team at same time, etc.)

Penalty time will display when player number is entered. You **must** enter both digits.

- **CLEAR A PENALTY:**

1. **HOME PENALTY** or **GUEST PENALTY**
2. **PENALTY CLEAR: YES** or **NO**